Busy Timer: Transition Table

Transition	Input / Event	Output / Action
BT-1	start_busy_timer	None.
BT-2	stop_busy_timer	None.
BT-3	start_busy_timer	Change state to restart the timer.
BT-4	stop_busytimer	None.
BT-5	busy_timer_timeout	Send indication that timer has expired.
BT-6	(Spontaneous)	Restart the timer.