Type 1 Ack Timer: Transition Table

Transition	Input / Event	Output / Action
ACK–TIMER–1	start_ack_timer (from Station Component)	None.
ACK–TIMER–2	stop_ack_timer (from Type1 SAP Component)	None.
ACK–TIMER–3	stop_ack_timer (from Type1 SAP Component)	Notify Station Component that ack timer has stopped.
ACK–TIMER–4	start_ack_timer (from Station Component)	Allow timer to continue; do not restart
ACK–TIMER–5	ack_timer_timeout	Send indication timer has expired to both SAP and Station Components
ACK–TIMER–6	stop_ack_timer (from Station Component)	None.
ACK–TIMER–7	stop_ack_timer (from Station Component)	Send indication to SAP Component that timer has stopped.