Type 1 TP Timer: Transition Table

Transition	Input / Event	Output / Action
TP-TIMER-1	start_TP_timer	None.
TP-TIMER-2	stop_TP_timer	Ignore.
TP-TIMER-3	start_TP_timer	Allow timer to continue; do not restart.
TP-TIMER-4	stop_TP_timer	None.
TP-TIMER-5	TP_timer_timeout	Send indication to Station Component that timer has expired.